



GLOBAL
TAPWARE



WALL INSTRUCTIONS



IMPORTANT - The Do's & Don'ts

[This is a budget end hose reel and as such it has natural limitations which require , you, the end user, to follow the below instructions.]

END USERS please read before using Reel.

- 1 - **Wipe the Hose** down **regularly** (WEEKLY or FORTNIGHTLY) with a '**Vegetable Oil**' only or use a '**Silicone Spray**'.

This will assist in:-

- (A) **Longevity of Hose.** – It reduces the chances of the hose breaking down (leaching) by various animal fats, MSG, other cooking ingredients or cleaning chemicals.

NOTE - If this leaching does happen it is not treated as a warranty issue but as a natural occurrence.

WHAT TO LOOK FOR –

The signs of the Hose starting to be damaged is when it starts to Harden at the Washdown Gun end (mostly) and then it starts to crack, then eventually breaks.

- (B) Easier constant rewinding & positioning of the hose in the casing.
- (C) Assists in the cleanliness of the hose.

OTHER HELPFUL HINTS

- 1- Where possible **Turn Wall Tap 'OFF'** at the end of the day and depressurize the Reel & Hose. Especially required for Hot water.
- 2- If going around corners or losing view of reel – **MARK THE HOSE** with **WARNING INDICATORS** to **STOP** pulling the hose any further.

HOW TO MARK HOSE:-

A - Pull the hose carefully all the way out to where you want it to reach to. – Make sure you do not **over stretch Hose.** – lay it on the floor.

(From the end of the Hose / Gun look back along the hose to where you lose view of the Hose REEL, this may be a corner. Walk to that point and with a Permanent Marker pen put **3 Ring Marks** around the hose. Then measure out 500mm towards the gun and put **2 Ring Marks** around hose, then repeat one more time with **1 Ring Mark.** – Those are your **3 warning signs** to **STOP** pulling the hose any further. To do so will / may cause damage inside the Reel.

- 3- **ALWAYS** take the Hose and Gun back to the Reel and help guide / Lay the hose with-in the reel.
- 4- **DO NOT** drop gun at the last operating position and then expect the Reel to drag it & the hose back in. This can cause issues later and damage both Gun, Hose & Reel.

**We will not warrant against poor operator behaviour,
Nor bad installations.**

P- 1300 85 25 15

E- sales.info@globaltapware.com